



The mounting holes on the main body of the pneumatic fastening clamps have been designed to allow installation direct on the female threaded holes or alternatively with through bolts.

Centering guide bushings  
GN 870



Centering guide bushings present an important function when mounting the pneumatic fastening clamps: they absorb lateral thrust and they ensure a precise alignment.




Clamp mounting brackets  
GN 873

Mounting of the cylinder by a collar clamp increases the numerous ways they can be installed.

Even collar clamps use centering guide bushings for precise positioning.

Clamping arms




Bracket


There is an extensive range of accessories available for pneumatic fastening clamps, such as tool holders (for clamping arms) thrust bolts and clamping jaws. The sketches shown on the right give some idea.

The combination of clamping tools on the clamping arm and brackets represent together a tool set.

Jaw blocks



For the fixing and precise positioning of clamping arms and jaw blocks, centering guide bushings GN 870 are also used. The individual data sheets give further information.



All pneumatic fastening clamps can be fitted with proximity switches (inductive sensors) to monitor the end position of the stroke.

1.1

1.2

1.3

1.4

2.1

2.2

2.3

2.4

